

READ BEFORE INSTALLATION!

Crawford Performance Plenum Supplemental Installation Instructions

For Complete Installation Instructions:

Go to www.crawfordzcar.com

Click on "SUPPORT" link

and then "PLENUM INSTALLATION MANUAL".

- 1.) Do not forget the 4 replacement bolts (provided with the plenum) that go into the lower plenum (the one that has the air horns and is not removed for this installation). They are cap bolts (no washers necessary) with Loctite already on them so they will not back out.
- 2.) You can reuse both existing gaskets. There is no need to replace them.
- 3.) When lowering the Crawford plenum down to meet up with the lower plenum, be careful not to get the rubber "cuff" around the oil filler cap stuck between the Crawford plenum and lower plenum.
- 4.) The nylon washers provided go between the top of the plenum and the head of the two bolts provided that go into the center supports of the Crawford plenum. The shorter of the two "long" bolts goes towards the front of the car. The bolts and washers will prevent any possible vacuum leaks.

If you have any problems or questions, please call us
Monday through Friday, 7:30AM-5:30PM CST
at 615-327-4159

Thanks and enjoy your new plenum!

Doug Stewart and the Crawford Crew

